




**AIR BAG 8**  
**9535-08, 9535-08L, 9535-08DC, 9535-08LDC**  
**AIR BAG 12**  
**9535-12, 9535-12L, 9535-12DC, 9535-12LDC**



Key Part #	Description	Key Part #	Description	Key Part #	Description		
9535-08	Air Bag 8 (15' Ducting)	4	9535-08G Grill (Air Bag 8)	8	9535-08F Rubber Feet, Set of 4 (Air Bag 8)		
9535-08L	Air Bag 8 (25' Ducting)		9535-12G Grill (Air Bag 12)		9535-12F Rubber Feet, Set of 4 (Air Bag 12)		
9535-08DC	Air Bag 8, DC (15' Ducting)		9534-02 Grill (Air Bag 8DC/LDC)		9505-06 Rubber Feet, Set of 4 (Air Bag 8DC/LDC & Air Bag 12DC/LDC)		
9535-08LDC	Air Bag 8, DC (25' Ducting)		9509-02 Grill (Air Bag 12DC/LDC)				
9535-12	Air Bag 12 (15' Ducting)	5	9535-08H Handle w/ Cord (Switch and screws included) (Air Bag 8)	9	9506-11 Fuse, 30 Amp (Air Bag 8DC/LDC & Air Bag 12DC/LDC)		
9535-12L	Air Bag 12 (25' Ducting)		9535-12H Handle w/ Cord (Switch and screws included) (Air Bag 12)	10	9534-04 Chassis (Air Bag 8DC/LDC)		
9535-12DC	Air Bag 12, DC (15' Ducting)		9513-07 Handle (Air Bag 8DC/LDC & Air Bag 12DC/LDC)		9509-05 Chassis (Air Bag 12DC/LDC)		
9535-12LDC	Air Bag 12, DC (25' Ducting)		6	9535-08M Motor (Air Bag 8)	11	9506-40 Cord w/ Battery Clamps (Air Bag 8 DC/LDC & Air Bag 12DC/LDC)	
1	9535-08D 15' Ducting (Air Bag 8)			9535-12M Motor (Air Bag 12)			
	9535-12D 15' Ducting (Air Bag 12)			9506-10 Motor (Air Bag 8DC/LDC & Air Bag 12DC/LDC)			
	9535-08DL 25' Ducting (Air Bag 8)			7	9535-08E Fan (Air Bag 8)	12	9513-09 Motor Clamp (Air Bag 8DC/LDC)
	9535-12DL 25' Ducting (Air Bag 12)				9535-12E Fan (Air Bag 12)		
2	9514-01B Duct Clamp (Air Bag 8 DC/LDC)				9534-05 Fan (Air Bag 8DC/LDC)		
	9535-12CP Duct Clamp (Air Bag 12 DC/LDC)				9509-06 Fan (Air Bag 12DC/LDC)		
3	9535-08C Blower Bag (Air Bag 8)						
	9535-12C Blower Bag (Air Bag 12)						