



## INSTALLATION, OPERATION & MAINTENANCE INSTRUCTIONS

1455 Kleppe Lane ♦ Sparks, NV 89431-6467 ♦ (775) 359-4712 ♦ Fax (775) 359-7424  
E-mail: [haws@hawsco.com](mailto:haws@hawsco.com) ♦ website: [www.hawsco.com](http://www.hawsco.com)

No. 2080222(16)

### **Model 9082 Sterile Antimicrobial Preservative Concentrate Eyewash Additive**

#### **TO ORDER MORE EYE WASH STATION PRESERVATIVE CONCENTRATE:**

Contact your nearest Haws Representative or call Haws Customer Service at  
1-888-640-4297, Sparks, Nevada.

#### **WARNING:**

1. MUST BE DILUTED WITH **POTABLE** WATER. DO NOT PUT DIRECTLY INTO EYES. Do not use if tamper evident twist-off top is broken or missing.
2. Contact with the eyes and mucosa can cause irritation, redness and pain.

#### **Mixing Instructions**

Follow instructions on the side of each bottle. Units with capacities of 5 gal - 20 gal (18.9 L – 75.7 L) should be mixed with the full 5 oz (148 ml) contained in each bottle. It is recommended that the tentative potable water be replaced every 90 days. (Water consumed in testing, should be replaced with clean potable water).

#### **Storage Instructions**

Product should be stored between 36° F - 104° F  
(2° C - 40° C) and used between 59° F - 86° F  
(15° C - 30° C). Use before expiration date.

36 Month shelf life after date of manufacture.

© 2016 Haws® Corporation – All Rights Reserved

HAWS® and other trademarks used in these materials are the exclusive property of Haws Corporation.